

<b>Brand</b>	<b>Models compatible with Blue&amp;Me™ (functions details available)</b>	<b>Other models potentially compatible</b>
<b>Asus</b>		P505
<b>Audiovox</b>	SMT 5600/Orange (HTC) C500	
<b>Benq Siemens</b>		
<b>BlackBerry</b>	8700, 8800	7100, 7290
<b>Hewlett Packard</b>	iPAQ 63xx, iPAQ 6515	iPAQ 6815
<b>i-Mate</b>	SP3, SP5/SP5m, K-Jam	JAM, Jamin, Jasjar, PDA2K, , SP3i
<b>LG</b>	U880, U8550, U900	U8210, U8360, Chocolate KG800
<b>Motorola</b>	A830/A835, A1000, E398, E1000, KRZR K1, MPX 220, RIZR Z3, SLVR L6, SLVR L7, V3 Razr, Razr V8, V500, V501, V525, V535, V545, V550, V600, V635	A780, E550, E680, PEBL U6, PEBL V6, ROKR E1, V80, V547, V557, V600i, V620, V1075
<b>Nec</b>		
<b>Nokia</b>	3230, 3600/3620/3650/3660, 5200, 6131, 6151, 6230/6230i, 6280, 6310/6310i, 6600, 6620, 6630, 6680/6681, 6810/6820/6822, 7600, 7610, 8800, 8910/8910i, 9500, E50,N70, N71, N73, N80, N91, N- Gage	3250, 5200, 6021, 6086, 6111, 6125, 6260, 6290, 6300, 6650, 6670, 7280, 7373, 7710, 9300, N75, N90, N-Gage QD
<b>Palm</b>		Treo 650, Treo 680, Treo 750
<b>Panasonic</b>		P341i, X11, X70, X88
<b>Philips</b>		
<b>Qtek</b>	8010, 8300/8310, 9100, S200, HTC P3300	8020, 8100, 8200, 9000, 9090, S100
<b>Sagem</b>		MYX-8, MYV-76
<b>Samsung</b>	D600, D820, D830, E250V, E570, E770/E780, i300, i550, i640, i750, i780, X820, Z230, Z500, Z510  Undisclosable: , ,	D500, E340, E390, E620, E720, E860, E880, I520, S500i/S501i, Z130, Z140/140V
<b>Sendo</b>		X, X2
<b>Sharp</b>		GX15/GZ100, GX25, GX30i/GX31/GX32, TM 200
<b>Siemens</b>	SL75	AP75, CX75/M75, S65, S66, SX1, SK65
<b>Sony Ericsson</b>	K530i, K550i, K700/K750i, K770i, K810i, M600i, P1i, S500i, P910i, T68/T68i, T606/T608/T610/T616/T618/T628/T630/T637, T650i, V800, W300i, W580i, W610i, W660i, W830, W850i, W880i, W910, W950i, W960, Z550i, Z600/Z608, Z1010  Undisclosable:	K600i/V600i, K608i, K790/K800, P990, S700/S700i/S710, W600i, W800/W800i, Z520i
<b>SPV</b>	C500, C600	
<b>Telit</b>	GU1100	Neo